

Wii Fit Balance Board Aerobic Step



Model : wii

Wii Fit Balance Board Aerobic Step

ZooZen Riiser Wii Fit Balance Board Aerobic Step

Description

The Riiser is a stand that you put under your Wii Fit balance board. It brings the top of the wii fit up to a full 4 inch height (10.2 centimeters), which is the standard height for step aerobics. When you are performing step exercises on the Wii Fit minigames, you will get a much better workout.



Wii Fit Balance Board Aerobic Step



Nintendo Wii > Wii Controllers > Wii Fit Balance Board Aerobic Step

Wii Fit Balance Board Aerobic Step



Wii Fit Balance Board Aerobic Step



Nintendo Wii > Wii Controllers > Wii Fit Balance Board Aerobic Step

Wii Fit Balance Board Aerobic Step

Prijs : €25.00

Dit artikel is toegevoegd op zaterdag 02 mei, 2009